

⚙️ B6.3 20 degree Front Bulkhead

Installation Tips

Start at +5 degree caster inserts for 20 + 5 overall. Then try less caster if you want more front grip and steering.



“20 Deg” text should go towards the front of the car for correct installation.

FRONT OF CAR

