


MST

max speed technology



ASSEMBLY KIT



TCR-M

RC 2WD HIGH PERFORMANCE RACING CAR

*532194 is only for assembly parts for roll 210/225 width 164.

INSTRUCTION MANUAL

ON ROAD USE ONLY


SPECIFICATION: 1:10 Racing Car
WHEELBASE: 210/225/233/239/245 mm
WIDTH: 164/173 mm
DRIVE MODE: FF/MR/RR
CASTER: 5 degrees
FULL BALL BEARING


www.rc-mst.com

* SPECIFICATION ARE SUBJECT TO CHANGE WITHOUT NOTICE


TCR-M

RC 2WD HIGH PERFORMANCE RACING CAR


**EXPLODED
VIEW****MST**
MAX SPEED TECHNOLOGY



NECESSARY TOOLS FOR ASSEMBLY 工具需求
(NOT INCLUDED IN KIT) [另購]



1.5 L wrench
1.5 L 板手



2.0 L wrench
2.0 L 板手




2.5 L wrench
2.5 L 板手




5.5 & 7.0 alum. wrench
5.5 & 7.0 套筒扳手




Hobby knife
美工刀



Scissors
剪刀









Side cutter
斜口鉗



Needle nose pliers
尖嘴鉗

Please follow the assembling figures and instructions closely
for your [TCR-M] best performance!
請依照說明書圖示步驟安裝以發揮 [TCR-M] 最好效能！

**FF**FRONT MOTOR
FRONT DRIVEPlease follow "FF" to assemble
組裝期間請依循 "FF" 字樣組裝**MR**MID MOTOR
REAR DRIVEPlease follow "MR" to assemble
組裝期間請依循 "MR" 字樣組裝**RR**REAR MOTOR
REAR DRIVEPlease follow "RR" to assemble
組裝期間請依循 "RR" 字樣組裝


210 225 233 239 245

210635

TCR-M lower deck 2.0 (210/225)
TCR-M 纖維底盤 2.0 (210/225)

210638

TCR-M lower deck 2.0 (233/239/245)
TCR-M 纖維底盤 2.0 (233/239/245)



WHEELBASE

Please follow "WB" to assemble
組裝期間請依循“軸距”組裝

210635 ————— 210mm
TCR-M lower
deck 2.0(210/225)
TCR-M 纤维底盘 2.0 (210/225) ————— 225mm

210638 ————— 233mm
TCR-M lower
deck 2.0
(233/239/245)
TCR-M 纤维底盘 2.0 (233/239/245) ————— 239mm ————— 245mm


Example of finished assembly configuration marking
成品完整配置標示範例

FF **210** **S**

Front motor front-wheel-drive 210mm
standard vehicle width
前置馬達前輪驅動 210mm 標準車寬

MR **239** **W**


Mid-mounted motor rear-wheel-drive 239mm
wide vehicle width
中置馬達後輪驅動 239mm 寬版車寬



**STANDARD
TRACK 164mm**



Please follow "S" to assemble
組裝期間請依循 "S" 字樣組裝



※ The shown widths are based on
the standard M car and MST M
car offset +1 wheel settings.
圖標尺寸是基於標準 M Car 輪框和
MST M Car 輪框 (Off set +1) 的設
定值。




**WIDER
TRACK 173mm**

Please follow "W" to assemble
組裝期間請依循 "W" 字樣組裝



STEP 1 Diff. set assembly
後擺臂組裝

Apply ball diff. grease to the differential during assembly.
請於滾珠上塗油



M2×4 screw ×8
圓頭螺絲



King pin joint ×4
大王銷球頭


M2×5 screw ×8
圓頭螺絲

King pin joint cover ×4
大王銷頭蓋


2×28 Shaft ×4
插銷

Lower arm mount ×4
下擺臂座


TRACK WIDTH




Upper arm (long) ×2 (pair)
上擺臂(長)



Lower arm (long) ×4
下擺臂(長)



Upper arm (short) ×2 (pair)
上擺臂(短)



Lower arm (short) ×4
下擺臂(短)

STEP 1 Front upper arm assembly
前上擺臂組裝

④ Upper arm (short)

① King pin joint cover


② M2×5

③ King pin joint

R

X2
Make 2

L



* Tighten M2×5 screw until king pin joint moving smoothly and no gap with upper arm.
上緊M2×5螺絲直至大王銷頭蓋順暢無間隙。


STEP 2 Front lower arm assembly
前下擺臂組裝

④ M2×4

② Lower arm (short)

① Lower arm mount

③ Shaft 2×28



X2
Make 2

STEP 1 Front upper arm assembly
前上擺臂組裝

④ Upper arm (long)

① King pin joint cover


② M2×5

③ King pin joint

R

X2
Make 2

L



* Tighten M2×5 screw until king pin joint moving smoothly and no gap with upper arm.
上緊M2×5螺絲直至大王銷頭蓋順暢無間隙。


STEP 2 Front lower arm assembly
前下擺臂組裝

④ M2×4








② Lower arm (long)







① Lower arm mount

③ Shaft 2×28












X2
Make 2

FRONT MOTOR
FRONT DRIVEM3×25 screw ×1
圓頭螺絲M3×20 screw ×1
圓頭螺絲M3×12 screw ×6
圓頭螺絲M3×10 screw ×8
圓頭螺絲4.8×4.5 Ball end ×2
球頭螺絲M3 nut ×6
螺帽Motor mount ×1
馬達座Bulkhead ×1 (pair)
側板Bulkhead ×1 (pair)
側板STEP 1 Front bulkhead assembly
前側板組裝※ Example of assembly is FF 225 S.
組裝圖例為 FF 225 S。STEP 2 Rear bulkhead assembly
後側板組裝



MID MOTOR
REAR DRIVEBulkhead ×1 (pair)
側板Bulkhead ×1 (pair)
側板Motor mount ×1
馬達座M3×25 screw ×1
圓頭螺絲M3×20 screw ×1
圓頭螺絲M3×12 screw ×6
圓頭螺絲M3×10 screw ×8
圓頭螺絲4.8×4.5 Ball end ×2
球頭螺絲M3 nut ×6
螺帽
STEP 1 Front bulkhead assembly
前側板組裝


※Example of assembly is MR 225 S.
組裝圖例為 MR 225 S。

STEP 2 Rear bulkhead assembly
後側板組裝


REAR MOTOR
REAR DRIVEBulkhead ×1 (pair)
側板Bulkhead ×1 (pair)
側板Motor mount ×1
馬達座M3×25 screw ×1
圓頭螺絲M3×20 screw ×1
圓頭螺絲M3×12 screw ×6
圓頭螺絲M3×10 screw ×8
圓頭螺絲4.8×4.5 Ball end ×2
球頭螺絲M3 nut ×6
螺帽
STEP 1 Front bulkhead assembly
前側板組裝



※Example of assembly is RR 225 S.
組裝圖例為 RR 225 S。

STEP 2 Rear bulkhead assembly
後側板組裝


WHEELBASE

210

225

M3×8 screw ×4
沉頭螺絲STEP 1 Front bulkhead assembly
前側板組裝※Example of assembly is FF 210 / 225 S.
組裝圖例為 FF 210 / 225 S。


WHEELBASE

210


225

STEP 2 Rear bulkhead assembly
後側板組裝 M3×8 screw ×4
沉頭螺絲

210



225



WHEELBASE


233

239

245


STEP 1 Front bulkhead assembly
前側板組裝M3×8 screw ×4
沉頭螺絲

233



239 245

R




WHEELBASE


233







239

245



STEP 2 Rear bulkhead assembly
後側板組裝M3×8 screw ×4
沉頭螺絲

245




M3×12 screw ×2
圓頭螺絲M3×25 screw ×2
圓頭螺絲4.8×4.5 Ball end ×2
球頭螺絲4.8 Adjuster +0 ×4
拉桿頭4.8 Adjuster +5 ×2
拉桿頭4.8 Adjuster +7 ×2
拉桿頭Servo saver cover ×1
伺服緩衝器蓋Servo saver mount 23T ×1
伺服緩衝座 23TServo saver mount 25T ×1
伺服緩衝座 25TServo horn ×1
伺服緩衝片Servo saver spring ×1
伺服緩衝彈簧Servo mount ×2
伺服機座STANDARD TRACK (WIDTH 164 mm)
標準車寬 (車寬 164 mm)STEP 1 Steering adjuster assembly
轉向拉桿組裝**X2**
Make 2STEP 2 Rear toe adjuster assembly
後束角拉桿組裝

STANDARD SUSPENSION

X4
Make 44.8 Adjuster has to be shortened by 3mm.
4.8 拉桿頭須修短 3mm。WIDER TRACK (WIDTH 173 mm)
寬版車寬 (車寬 173 mm)STEP 1 Steering adjuster assembly
轉向拉桿組裝**X2**
Make 2STEP 2 Rear toe adjuster assembly
後束角拉桿組裝

LONG SUSPENSION



X4
Make 44.8 Adjuster has to be shortened by 1mm.
4.8 拉桿頭須修短 1mm。

TRACK WIDTH



M2.5×16 screw ×1
圓頭螺絲




M3×16 screw ×1
圓頭螺絲

STEP 3 Servo & servo saver assembly
伺服機組裝

210

225

 M3×8 screw ×4
沉頭螺絲

 M2.5×6 screw ×4
沉頭螺絲
Battery mount ×1
電池座Battery mount ×1
電池座Battery mount ×1
電池座
STEP 1 Steering servo & battery mount assembly
轉向伺服機 & 電池座組裝



FF

FRONT MOTOR
FRONT DRIVE

233


239

245




STEP 1 Steering servo & battery mount assembly
轉向伺服機 & 電池座組裝

⑧ Battery mount



③ Rear toe adjuster


④ Battery mount



⑤ Battery mount

⑥ R5.0 R-Clip

① Steering set



⑦ M3×8

※ Example of assembly is FF 239 S.
組裝圖例為 FF 239 S。

239



245

FF

FRONT MOTOR
FRONT DRIVE

210

225

M3×8 screw ×4
沉頭螺絲M2.5×6 screw ×4
沉頭螺絲Battery mount ×1
電池座Battery mount ×1
電池座Battery mount ×1
電池座MID MOTOR
REAR DRIVE※ Example of assembly is MR 255 S.
組裝圖例為 MR 255 S。STEP 1 Steering servo & battery mount assembly
轉向伺服機 & 電池座組裝

③ Rear toe adjuster

⑧ Battery mount

④ Battery mount


① Steering set

⑤ Battery mount

② M2.5×6


⑦ M3×8

⑥ R5.0 R-Clip



233

239 245



233


STEP 1 Steering servo & battery mount assembly
轉向伺服機 & 電池座組裝

※ Example of assembly is MR 239 S.
組裝圖例為 MR 239 S。

239



245

MR MID MOTOR REAR DRIVE




210

225

M3×8 screw ×4
沉頭螺絲M2.5×6 screw ×4
沉頭螺絲Battery mount ×1
電池座Battery mount ×1
電池座Battery mount ×1
電池座STEP 1 Steering servo & battery mount assembly
轉向伺服機 & 電池座組裝


RR

REAR MOTOR
REAR DRIVE※ Example of assembly is RR 255 S.
組裝圖例為 RR 255 S。

233

239

245




233

239

245

※ Example of assembly is RR 239 S.
組裝圖例為 RR 239 S。

STEP 1 Steering servo & battery mount assembly
轉向伺服機 & 電池座組裝



RR

REAR MOTOR
REAR DRIVE