

#73022 - Wide Front Bumper for the Losi Mini 8ight 2.0

□ **What's Included:** 1 - Front Bumper, 1 - Gearbox Spacer & 2 - M2.5 x 12mm flathead screws.

□ **Disassembly:** Remove and discard the two flathead screws holding the stock front bumper (Losi #LOSB1907) to the front gearbox. Take note of the slot from which the bumper was removed since the **RPM** Gearbox Spacer will slip into this location.

□ **Gearbox Spacer:** Note the proper orientation of the Gearbox Spacer using the illustration below for reference. Slip the Gearbox Spacer between the chassis and the gearbox, with the fingernail pull towards the top of the vehicle.

□ **Final Assembly:** Place the front bumper against the front of the chassis, slipping the two raised bosses of the **RPM** bumper into the flathead countersinks of the chassis. Using the two included M2.5 x 12mm flathead screws, bolt the assembly together, making sure the screws go through the Gearbox Spacer.

