

## #73562 & # 73565 Traxxas LCG Front Bulkhead for the Slash 4x4 & Rally 4x4

**What's Included:** 1 - Chassis Mount, 1 - Differential Mount & 3 - M4 x 12mm Flathead Screws.

**Assembly:** 1) Install the bellcranks on the Chassis Mount, then connect the steering linkage to the steering servo horn. **Important Note:** When installing the bellcranks, **use extreme caution** and do not over-tighten the two retaining screws at the top of the bellcrank posts. Over-tightening these screws can cause binding of the top bearings and can potentially break off the bellcrank posts. Damage due to incorrect installation is not covered under the **RPM** warranty program. 2) Bolt the Chassis Mount to the chassis using two stock M4 x 10mm buttonhead screws. 3) Install the differential on to the Differential Mount using stock hardware. 4) Thread the three supplied M4 x 12mm flathead screws through the Differential Mount into the Chassis Mount.

**Important Note:** **RPM** Differential Mount to Chassis Mount screws **install on an angle**. Do not attempt to drive them in straight. 5) Finish by installing any remaining stock parts and hardware.

