

#73432 - Front A-arms for the Associated B44, B44.1 & B44.2

Anti-Sway Bar Ball Stud Installation: *RPM* B44 front a-arms require **Associated #6276** ball studs or any other 4.3mm ball stud with a 4-40 x 1/4" thread (not included) to install sway bars. Using a 2mm (or 5/64") hex wrench, align the ball stud with the hole as shown. Thread until snug only! Do not overtighten.

Warning: Do not use any hex wrench that will not fit through the hole. Enlarging the hole will void the *RPM* warranty on the a-arms.

