

## #70902 & #70905 - Front Bumper for the Associated SC10

**Before You Begin:** Check the contents of this package. Included are one front bumper, one front skid plate, one front chassis brace, three 4-40 x ½" button-head screws, two 4-40 locknuts, four 4-40 x 7/8" flathead screws and two 4-40 x ½" flathead screws.

**Disassembly:** Remove the front bumper by removing and discarding the two 4-40 screws holding the stock front bumper brace to the front shock tower. Remove and discard the two 4-40 screws holding the front bumper skid plate to the front bulkhead. Remove and discard the two remaining screws that attach the chassis to the front bulkhead. **Remove and retain** the two 4-40 x 3/8" flathead servo mounting screws. They will be used later.

### **Assembly:**

1) Find and identify the **RPM** logos on both the front bumper and the skid plate (the skid plate is the piece with the **RPM** logo in the center). Orient them so they read right side up on both parts. Using the three included 4-40 x ½" button-head screws, slide them through the skid plate and thread them into the front bumper. **Caution - Do Not Over-Tighten the Screws!** Stripped threads are not covered under **RPM** warranty protection.

2) Align the skid plate on the **RPM** chassis brace. The rib on the back of the skid plate will rest against the front edge of the brace. Using the two 4-40 x 3/8" flathead screws you removed from the servo mounts, slide them through the front two holes in the skid plate (closest to the **RPM** logo), through the chassis brace and lock them in place with the included 4-40 locknuts.

3) Place the chassis brace against the chassis. The rear two screw holes will align with the servo mounting holes. Use the included two 4-40 x ½" flathead screws to bolt the chassis brace to the chassis and into the servo mounts.

4) Finally, use the four included 4-40 x 7/8" flathead screws to bolt the front bumper assembly to the front bulkhead.

**Suggestions:** For a scale desert truck look or for nighttime fun, please consider **RPM** light housing sets **#80982** - black or **#80983** - chrome. This is a 4 light housing set that mounts in between the upper and lower bars of your new **RPM** front bumper. Included with the light housing sets are instructions on how to install LED lights (not included) for nighttime runs! Please see our website FAQ pages for more information.