

SET-UP SHEET

XRAY X32.20

[illegible][illegible][illegible]

The diagram shows a top-down view of a vehicle chassis with various components labeled and options selected. The components and their options are as follows:

- FRONT TIRE:** 1
- EXTENSION:** 0 SLOTS, 1 SLOT, 2 SLOTS (2 SLOTS is selected with an 'X')
- WHEELBASE:** 0 INCH
- ROLL CENTER:** ROLL LOW, HARD, ALL (HARD is selected with an 'X')
- UPPER DECK:** NO LOAM, HARD (HARD is selected with an 'X')
- BATTERY PLACEMENT:** LONG SIZE FRONT, LONG SIZE REAR (LONG SIZE REAR is selected with an 'X')
- BATTERY SIZE:** STD. SHORT, LOW SHIRT (STD. SHORT is selected with an 'X')
- UPPER B RACE:** YES (YES is selected with an 'X'), NO
- ROLL CENTER:** COMPOSITE (COMPOSITE is selected with an 'X'), ALL
- REAR TIRE:** 3
- WHEELBASE:** 3 INCH
- OFFSET:** 3 INCH

The chassis diagram includes labels for various parts: FRONT TIRE, EXTENSION, WHEELBASE, ROLL CENTER, UPPER DECK, BATTERY PLACEMENT, BATTERY SIZE, UPPER B RACE, ROLL CENTER, REAR TIRE, and WHEELBASE. The diagram also shows the location of the battery, engine, and other components.

The diagram illustrates the chassis components for a vehicle. It includes a top view of the chassis with four wheels. The steering arms are labeled 'STEERING ARMS' and 'STEERING PLATE'. The eccentric bushings are labeled 'ECCENTRIC BUSHINGS'. The diagram shows the assembly of the steering arms, steering plate, and eccentric bushings. The steering arms are connected to the steering plate. The eccentric bushings are connected to the steering arms. The diagram also shows the assembly of the steering arms, steering plate, and eccentric bushings. The steering arms are connected to the steering plate. The eccentric bushings are connected to the steering arms.

FRONT CAMBER		2°								
										
<table border="1"> <tr> <td>FRONT ARM</td> <td>☐</td> </tr> <tr> <td>BEUDJIN</td> <td>☐</td> </tr> <tr> <td>HYSD</td> <td>☒</td> </tr> <tr> <td>GRVPH E</td> <td>☐</td> </tr> </table>			FRONT ARM	☐	BEUDJIN	☐	HYSD	☒	GRVPH E	☐
FRONT ARM	☐									
BEUDJIN	☐									
HYSD	☒									
GRVPH E	☐									
<table border="1"> <tr> <td>REAR HEIGHT</td> <td>23</td> </tr> <tr> <td>REAR HEIGHT</td> <td>21</td> </tr> </table>			REAR HEIGHT	23	REAR HEIGHT	21				
REAR HEIGHT	23									
REAR HEIGHT	21									
										
DIFF HEIGHT		2								
										
<table border="1"> <tr> <td>REAR ARM</td> <td>☐</td> </tr> <tr> <td>BEUDJIN</td> <td>☐</td> </tr> <tr> <td>HYSD</td> <td>☒</td> </tr> <tr> <td>GRVPH E</td> <td>☐</td> </tr> </table>			REAR ARM	☐	BEUDJIN	☐	HYSD	☒	GRVPH E	☐
REAR ARM	☐									
BEUDJIN	☐									
HYSD	☒									
GRVPH E	☐									

[illegible]