

**REFLEX**

Art.Nr.	Bezeichnung	BEC	Empfänger
500500100	REFLEX Wheel Start blau	-	500501543
500500101	REFLEX Wheel Start neongelb	-	500501543
500500102	REFLEX Wheel Start schwarz	-	500501543
500500103	REFLEX Wheel Start weiss	-	500501543
500500048	REFLEX Wheel X1	-	500501533, 500501534, 500501535, 500501536
500500095	REFLEX Wheel X1 Camouflage	-	500501533, 500501534, 500501535, 500501536
500500096	REFLEX Wheel X1 Carbon	-	500501533, 500501534, 500501535, 500501536
500500052	REFLEX Wheel Pro III	-	500501533, 500501534, 500501535, 500501536, 500501538, 500501539
500500053	REFLEX Wheel Pro III	X	500501535, 500501536, 500501533, 500501534, 500501538, 500501539
500500054	REFLEX Wheel Pro III LCD	-	500501533, 500501534, 500501535, 500501536, 500501538, 500501539
500500055	REFLEX Wheel Pro III LCD	X	500501535, 500501536, 500501533, 500501534, 500501538, 500501539
500500056	REFLEX Wheel Pro III LCD WP	X	500501536, 500501535, 500501533, 500501534, 500501538, 500501539
500500083	REFLEX Wheel Pro III Telemetry	X	500501542
500500084	REFLEX Stick Pro III 4CH	-	500501533, 500501534, 500501535, 500501536, 500501538, 500501539
500500085	REFLEX Stick Pro III LCD 4CH	-	500501533, 500501534, 500501535, 500501536, 500501538, 500501539
500500517	REFLEX Stick Pro III	-	500501533, 500501534, 500501535, 500501536
500501006	REFLEX Stick II 6-Kanal	-	500501537, 500501533, 500501534, 500501535, 500501536
500501003	REFLEX Stick Multi Pro 14	-	500501540, 500501537, 500501533, 500501534, 500501535, 500501536
500501004	REFLEX Stick Multi Pro LCD 14	-	500501544, 500501533, 500501534, 500501535, 500501536
500500522	REFLEX Wheel Ultimate Touch 2.0	-	500501541